

# COSY IN GREY

## CLEANING / RENGØRING / SÄUBERN / NETTOYAGE / LIMPIEZA


EN: Turn off electricity, clean with dry or moist cloth

DK: Afbryd elektricitet, rengør med tør eller fugtig klud


FR: Coupez l'électricité et nettoyez avec un chiffon sec ou humide

ES: Desconectar la corriente eléctrica y limpiar con el paño seco o húmedo


DE: Vom strom trennen, mit einem sauberen, trockenen oder feuchten tuch.



**CONTENT / INDHOLD / INHALT / CONTENU / CONTENIDO:**



**ASSEMBLY INSTRUCTION / SAMLE MANUAL / MONTAGEANLEITUNG /  
INSTRUCTIONS DE MONTAGE / INSTRUCCIONES DE MONTAJE :**



Item: 01033  
Item Name: Cosy In Grey Lamp  
1XE27, bulb Min.25W-Max.60W  
Caution: Only dimmable bulb  
can be used  
220-240V, 50/60Hz  
CE IP20