


> INSTRUCTION MANUAL <

---

# HACKNEY



By HAY

**HAY**

> INTRODUCTION <

---

With its contemporary lines, high comfort level and manoeuvrability, the Hackney sofa and Lounge chair strikes the perfect balance between modern and traditional styling.

It features a fully upholstered foldable frame that can be disassembled into three sections and transported with ease.

Constructed with a wooden frame featuring a coil spring system wrapped in down and polyurethane foam, it offers soft, comfortable seating that retains its shape.

Its modest, technically accomplished design makes it ideal for environments with restricted access or where it might need frequent moving.

#### CAUTION

With a little care you can prolong the life of your furniture. Follow the instructions for the materials of your specific product to make sure that it stays in the best shape for as long as possible.

The information below is only intended as a general guideline. For more information on how to remove specific stains, please inquire where you bought the furniture.


- When you move the furniture, make sure to lift it rather than pulling or pushing it to avoid damaging the floor, legs and mountings.
- The sofa is heavy. Moving and lifting heavy goods can cause injury, so please be careful when moving it. We advise that four people should be used to move the whole sofa, and two people to move the individual sections (seat base and backrest/armrest).
- Always remove stains quickly before they can do any permanent damage to the furniture.

- Avoid placing the furniture in direct sunlight or near a strong heat source to reduce changes. HAY only uses top-quality fabrics but all fabrics fade, and seams weaken, when exposed to sunlight or strong heat.
- Avoid improper use such as sitting on the back or armrests, putting your feet on the furniture or standing on the it.
- Smooth out creases and wrinkles with your hand after use to even out the fabric and prevent seam lines from being skewed.
- Flip the cushions regularly to avoid patinating on one side only.
- Plump the cushions and mattress regularly to maintain the shape.

#### FABRICS


- Vacuum the furniture regularly using the upholstery nozzle to remove dust and avoid fluff and pilling.
- Straighten the fabric with your hands from time to time. Wrinkles in the fabric can be straightened using a steamer.
- Soak up spilled liquids immediately with an absorbent napkin or cloth by dabbing gently towards the centre of the stain.
- Most stains can be removed with lukewarm water on a clean lint-free cloth. If necessary, add a little neutral detergent. Avoid rubbing the material hard as this could result in loss of colour and damage the fabric. It may also be necessary to use a hairdryer to avoid leaving an outline.
- Never use concentrated detergents or bleach, ammonia or soap intended for hard surfaces.

Your Hackney comes preassembled, but should you wish to disassemble, please follow these steps.



1.


Remove all cushions, including the mattress.



2.

Lift the end of the seat base so that the metal clips unhook. Move the arms of the sofa outwards. Repeat on the other side of the seat base.


WARNING: The sofa is heavy, so it is advised that two or more people complete this step.



3.

Lift the seat base so that the central metal clip unhooks.


WARNING: The sofa is heavy, so it is advised that two or more people complete this step.



4.



You can now move the heavy sections of the sofa individually.

WARNING: The sofa is heavy, so it is advised that two people or more complete this step.




5.

To re-assemble, please reverse the steps. It is important that you push any excess material in the fold joint before re-positioning to ensure a neat and tidy fold.




## MAINTENANCE

Your sofa will need some attention regularly to ensure that the cushions are plump and the mattress keeps its shape.




1.

Straighten out any creases and lumps in the mattress with your hands.




2.

Plump the individual cushions regularly.




3.

Smooth out the fabric on the arm/backrest joint.




4.

Run your hands along the armrest and back to remove any creases.



5.

With regular attention and care, your sofa will keep its shape and stay comfortable.



Havnen 1 8700 Horsens Denmark  
+45 4282 0282 / hay@hay.dk

**HAY**

21032017

ITEM NO. 706316



5 710441 245377